

# EOS-180W-24V-ENCLOSURE-HD


180W /24V CONSTANT CURRENT / VOLTAGE LED DRIVER WITH ENCLOSURE

**General** - The general design, shape and arrangement shall be as shown except where variations are specifically described. All dimensions are nominal, within engineering tolerances, except where specifically indicated as a minimum or a maximum. This Power supply is for remote mounting and is to provide power to eos Light Panel<sup>™</sup> System.

- 1. LED Driver Enclosure Metal, overall atleast 31 cm (12.20 in.) by 25.7 cm (10.11 in.) by 10.4 cm (4.09 in.), by 1.60 mm (0.063 in.) min. thickness, provided with standard conduit knockouts on one side for the input, and provided with ) standards knockouts at the output side. Provided with metal cover secured to the enclosure by mechanical means, min. thickness approx. atleast 1.2 mm (0.047 in.).
- 2. LED drivers: Constant Voltage + Constant Current mode output. 24V. 90W each.
- 3. Grounding See ground strap in the images below.




ENCLOSURE WITH 2 DRIVERS (180W) and DECODER





### 5 Channel RDM DMX512 Decoder



Product Data:	Input Voltage	Output Current	Output Power	Remarks	Size(LxWxH)	Protection
	12-24VDC	5x8A	5x(96-192)W	Constant voltage	164x73x38mm	Short circuit
	12-48VDC	5x350mA	5x(4.2-16.8)W	Constant current 164x73x38mm		Short circuit
	12-48VDC	5x700mA	5x(8.4-33.6)W	Constant current	164x73x38mm	Short circuit

- Master & decoder mode, RDM function
- Metal housing, digital display to show data directly, easily to set and show DMX address.
- With multiple kinds of DMX in/out ports: RJ 45, XLR , normal screws.
- Total 5 PWM output channels, common anode. DMX channel quantity from 1CH~5CH settable
- · PWM output resolution ratio 8bit , 16bit settable.
- Output PWM frequency from 500HZ ~ 30K HZ settable.
- Output dimming curve gamma value from 0.1 ~ 9.9 settable.
- Decoding mode settable.
- Galvanic isolation
- Safety & Warnings: DO NOT install with power applied to device. • DO NOT expose the device to moisture.

#### Operation

Before you do other settings, please set the device to be Master or Decoder mode.

 $r \sqcup n i = DMX$  Decoder mode ,  $r \sqcup n i = DMX$  Master mode(stand alone).

Keep on clicking Down button, to get run1 or run2, then click Enter, then click Down button to choose 1 or 2, then click Back button. After choose run1 or run2, please power off and power on again the device.



I. For run2 DMX Master mode: After power on the device, if keep on clicking Up button, you will find below menu on display:

Means brightness for each output PWM channel. First 1 means PWM output channel 1 and it is selectable from 1 to 5 by clicking "UP" or "Down" button. Second 01 means brightness level, click "Enter" button, the display flashes, then click "UP" or "Down" button to select from 00-99-FL, which means 0%-99%-100% brightness, then click "Back" button to confirm. XXX Means programs , total 1~31 programs.

- .XX Means RGB running effect's brightness, total 1~8 levels brightness
- $\sum_{i=1}^{n} \sum_{j=1}^{n} X$  Means effect play speed. total 1~9 levels speed.

P-XX means RGB color changing modes, total 31 programs:


- 00- RGB off
- 01- Static red
- 02- Static green
- 03- Static blue
- 04- Static yellow (50% red+50% green)
- 05- Static orange (75% red+25% green)
- 06- Static cyan (50% green+50% blue)
- 07- Static purple (50% blue+50% red)

08- Static white (100% red+100% green+100% blue)

09- Any two colors of RGB mix fade, changing diagram as follow:



13- RGB FADE IN, changing diagram as follow:



12- RGB jump changing, changing diagram as follow:



#### 14- RGB FADE OUT, changing diagram as follow:

15- RGB 3 colors strobe

- 16- White color strobe (100% red+100% green+100% blue)
- 17-7 colors FADE OUT & FADE IN (red, orange, yellow, green, cyan, blue, purple FADE OUT & FADE IN)
- 18-7 colors jump changing (red, orange, yellow, green, cyan, blue, purple jump changing)
- 19-7 colors strobe (red, orange, yellow, green, cyan, blue, purple strobe)
- 20- Red-white (100% red+100% green+100% blue) circle gradual changing
- 21- Green-white (100% red+100% green+100% blue) circle gradual changing
- 22- Blue-white (100% red+100% green+100% blue) circle gradual changing
- 23- Red-orange circle gradual changing
- 24- Red-purple circle gradual changing
- 25- Green-yellow circle gradual changing
- 26- Green-cyan circle gradual changing
- 27- Blue-purple circle gradual changing
- 28- Blue-cyan circle gradual changing
- 29- Red-yellow-green circle gradual changing
- 30- Red-purple-blue circle gradual changing
- 31- Green-cyan-blue circle gradual changing

**II. For run1 DMX decoder mode:** After power on the decoder, if keep on clicking Up button, you will find below menu on display:

DMX signal indicator  $\bullet$  :: When DMX signal input is detected, the indicator on the display following after  $\square$  turns on red  $\square$  XXX

- XXX Means DMX address. fa ctory defaults setting is 001.
- **B** XX Means DMX channels quantity. factory defaults setting is Ch05
- A XX Means Bit (8bit or 16bit). factory defaults setting is 16bit

310.616.5056

- BAX Means output PWM frequency. factory defaults setting is 1K HZ
- BRXX Means output dimming curve gamma value, factory defaults setting is ga 1.5
- **B XX** Means Decoding mode, factory defaults setting is dp1.1

310.616.5070


🗰 eoslight.com




By holding button Back + Enter together at the same time over 5 seconds until the display go off, it will restore default settings .

#### Wiring diagram

1.Work as Master mode



2.Work as Decoder mode



#### 1. DMX address setting:

select menu  $\frac{1}{2}$  XXX , click button "Enter", display flashes, then click or hold button "Up" / "Down" to set DMX address (click is slow, hold is fast.), then click button "Back" to confirm.

#### 2. DMX channel quantity setting:

Select menu Select menu Select menu Status (1,2,3,4,5) is address 001,002,003,004,005.


#### 3. PWM output resolution Bit setting:

select menu 🗧 🕻 XX, click button "Enter", display flashes, then click button "Up" / "Down" to choose 08 or 16 bit, then click button"Back" to confirm.

#### 4. output PWM frequency setting:

#### 5. output dimming curve gamma value setting:

select menu B RXX, click button "Enter", display flashes, then click or hold button "Up" / "Down" to choose 0.1~9.9, then click button "Back" to confirm.



#### 6. DMX decoding mode setting:

Select menu XX, click button "Enter", display flashes, then click or hold button "Up" / "Down"to choose the decoding mode, then click button "Back" to confirm. "dPxx" means the DMX address quantity used for control of corresponding PWM output channel quantity. 1st "x" is DMX address quantity, 2nd "x" is PWM channel quantity.

Micro dimming: the micro dimming effect can only be visible when the dimming curve gamma value is set lower than 1.4, and the lower the value is, the more visible the micro dimming effect will be.

#### DMX address is 001, CH01

DMX Console Slider number DMX channel	dp1.1	dp2.1
1	for all output dimming	for all output dimming
2	No use	for all output micro dimming

DMX address	is	001,	CH02	

DMX Console Slider number DMX channel	dp1.1	dp2.1	dp3.2
1	for output 1&3 dimming	for output 1&3 dimming	for output 1&3 dimming
2	for output 2,4 &5 dimming	for output 1&3 micro dimming	for output 2,4 &5 dimming
3		for output 2,4 &5 dimming	for all output dimming
4		for output 2,4&5 micro dimming	

#### DMX address is 001, CH03

DMX Console Slider number DMX channel	dp1.1	dp2.1	dp4.3	dp5.3
1	for output 1 dimming	for output 1 dimming	for output 1 dimming	for output 1 dimming
2	for output 2 dimming	for output 1 micro dimming	for output 2 dimming	for output 2 dimming
3	for output 3,4 &5 dimming	for output 2 dimming	for output 3,4&5 dimming	for output 3,4&5 dimming
4		for output 2 micro dimming	for all output master dimming	for all output master dimming
5		for output 3,4 &5 dimming		strobe effects
6		for output 3,4&5 micro dimming		

#### DMX address is 001, CH04

DMX Console Slider number DMX channel	dp1.1	dp2.1	dp5.4	dp6.4
1	for output	for output	for output 1	for output 1
	1 dimming	1 dimming	dimming	dimming
2	for output 2	for output 1	for output 2	for output 2
	dimming	micro dimming	dimming	dimming
3	for output 3	for output 2	for output 3	for output 3
	dimming	dimming	dimming	dimming
4	for output 4&5	for output 2	for output 4&5	for output 4&5
	dimming	micro dimming	dimming	dimming

122 W. 26th St., Suite 503, New York, NY 10001

310.616.5070

🛱 310.616.5056 🌐 eoslight.com

5	for output 3 dimming	for all output master dimming	for all output master dimming
6	for output 3 micro dimming		strobe effects
7	for output 4 &5 dimming		
8	for output 4&5 micro dimming		

#### DMX address is 001, CH05

DMX Console Slider number DMX channel	dp1.1	dp2.1	dp6.5	dp7.5
1	for output 1 dimming	for output 1 dimming	for output 1 dimming	for output 1 dimming
2	for output 2 dimming	for output 1 micro dimming	for output 2 dimming	for output 2 dimming
3	for output 3 dimming	for output 2 dimming	for output 3 dimming	for output 3 dimming
4	for output 4 dimming	for output 2 micro dimming	for output 4 dimming	for output 4 dimming
5	for output 5 dimming	for output 3 dimming	for output 5 dimming	for output 5 dimming
6		for output 3 micro dimming	for all output master dimming	for all output master dimming
7		for output 4 dimming		strobe effects
8		for output 4 micro dimming		
9		for output 5 dimming		
10		for output 5 micro dimming		

### The data definitions for strobe channel are as follows:

{0, 7},//undefined {8, 65},//slow strobe-->fast strobe {66, 71},//undefined {72, 127},//slow push fast close {128, 133},//undefined {134, 189},//slow close fast push {190, 195},//undefined {196, 250},//random strobe {251, 255},//undefined

#### The supported RDM PIDs are as follows:

DISC\_UNIQUE\_BRANCH DISC\_MUTE DISC\_UN\_MUTE DEVICE\_INFO DMX\_START\_ADDRESS IDENTIFY\_DEVICE SOFTWARE\_VERSION\_LABEL DMX\_PERSONALITY DMX\_PERSONALITY\_DESCRIPTION SLOT\_INFO SLOT\_DESCRIPTION MANUFACTURER\_LABEL SUPPORTED\_PARAMETERS


#### **Restore to Factory Default Setting**


Press and hold down both "Back" and "Enter" keys until the digital display turns off, then release the keys, system will reset and the digital display will turn on again, all settings will be restored to factory default. Default settings are as follows: DMX Address Code: a001 DMX Address Quantity: SW1=0: ch05, SW1=1: ch04 PWM Resolution Mode: bt16 PWM Frequency: pf01 Gamma: ga1.5 Decoding Mode: dp1.1


#### Short circuit protection

If short circuit of the connected load is detected, the display will flash to alarm and the load will be forced to open circuit status. Once the fault is removed, the decoder will recover after re-powered on.

#### **Product Dimension**













### □ 🗑 🗇 🤍 🤍 🦉 SELV IP67 🕞 c 🅦 us 🐼º⁵ [Ħ. @ CBCE

### Features

- Constant Voltage + Constant Current mode output
- Plastic housing with Class II design
- · Built-in active PFC function
- Class 2 power unit(except NPF-90-12/15)
- No load power consumption <0.15W</li>
- · IP67 rating for indoor or outdoor installations
- Typical lifetime>50000 hours
- 5 years warranty

### Description

NPF-90 series is a 90W AC/DC LED driver featuring the dual modes constant voltage and constant current output. NPF-90 operates from  $90 \sim 305$ VAC and offers models with different rated voltage ranging between 12V and 54V. Thanks to the hign efficiency up to 91%, with the fanless design, the entire series is able to operate for  $-40^{\circ}$ C  $\sim +85^{\circ}$ C case temperature under free air convection. The entire series is rated with IP67 ingress protection level and is suitable to work for a variety of applications at dry, damp or wet locations.



### LED panel lighting

LED downlight

Applications

- LED decorative lighting
- LED tunnel lighting
- Moving sign




#### SPECIFICATION


MODEL		NPF-90-12	NPF-90-15	NPF-90-20	NPF-90-24	NPF-90-30	NPF-90-36	NPF-90-42	NPF-90-48	NPF-90-54
	DC VOLTAGE	12V	15V	20V	24V	30V	36V	42V	48V	54V
	CONSTANT CURRENT REGION Note.2	7.2 ~ 12V	9~15V	12~20V	14.4~24V	18 - 30V	21.6~36V	25.2~42V	28.8~48V	32.4 - 54V
	RATED CURRENT	7.5A	6A	4.5A	3.75A	3A	2.5A	2.15A	1.88A	1.67A
	RATED POWER Note.5	90W	90W	90W	90W	90W	90W	90,3W	90.24W	90.18W
OUTPUT	RIPPLE & NOISE (max.) Note.3	150mVp-p	150mVp-p	150mVp-p	150mVp-p	200mVp-p	200mVp-p	250mVp-p	250mVp-p	350mVp-p
oun or	VOLTAGE TOLERANCE Note.4	±4.0%	±4.0%	±4.0%	±3.0%	±3:0%	±2.0%	±1.0%	±1.0%	±1.0%
	LINE REGULATION	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%	+0.5%	±0.5%
	LOAD REGULATION	±1.5%	±1.0%	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%	±0.5%
	SETUP, RISE TIME Note.6	500ms, 80m	s 115VAC/23	BOVAC			E.e.			
	HOLD UP TIME (Typ.)	16ms/230VAC 16ms/115VAC								
- /	VOLTAGE RANGE Note.5	90 ~ 305VAC 127 ~ 431VDC (Please refer to "STATIC CHARACTERISTIC" section)								
	FREQUENCY RANGE	47~63Hz								
	POWER FACTOR	PF ≥ 0.98/115VAC, PF ≥ 0.96/230VAC, PF ≥ 0.94/277VAC@full load (Please refer to "POWER FACTOR (PF) CHARACTERISTIC" section)								
	TOTAL HARMONIC DISTORTION			15VC,230VAC ARMONIC DIS						1.0
INPUT	EFFICIENCY (Typ.)	89%	89.5%	90.5%	91%	89.5%	90.5%	90.5%	90.5%	90.5%
1998 B.Y.	AC CURRENT	0.95A / 115V		/ 230VAC	0.4A/277VAC	1.1.1.1.1.1.1		and the second s		
	INRUSH CURRENT(Typ.)	COLD STAR			ed at 50% lpea	k) at 230VAC: 1	Per NEMA 410			
	MAX. No. of PSUs on 16A CIRCUIT BREAKER	COLD START 60A(twidth=550µs measured at 50% lpeak) at 230VAC; Per NEMA 410 3 units (circuit breaker of type B) / 6 units (circuit breaker of type C) at 230VAC.								
	LEAKAGE CURRENT	<0.25mA/277VAC								
	NO LOAD POWER CONSUMPTION									
	NO LOAD FOWER CONSUMPTION									
	OVER CURRENT	95 - 108%								
		Constant current limiting, recovers automatically after fault condition is removed Hiccup mode, recovers automatically after fault condition is removed								
PROTECTION	SHORT CIRCUIT	15~17V	17.5 - 21V	23~27V	28~34V	34 ~ 40V	41~46V	46~54V	54~60V	59-66V
- NOILE HOR	OVER VOLTAGE			and the second second			41~40V	40~ 34V	34~00V	39~000
	OVER TEMPERATURE	Shut down and latch off o/p voltage, re-power on to recover Shut down o/p voltage, re-power on to recover								
	WORKING TEMP.			and the second second	Property and Particle Street	TEMPEDATIN	E" contion)			
	MAX. CASE TEMP.	Tcase=+40 ~ +85°C (Please refer to " OUTPUT LOAD vs TEMPERATURE" section)								
	WORKING HUMIDITY	Tcase=+85°C 20 ~ 95% RH non-condensing								
CHRIDONNEUT	STORAGE TEMP., HUMIDITY			ing						
ENVIRONMENT										
	TEMP. COEFFICIENT	±0.03%/C (0 ~ 50°C)								
	VIBRATION	10 ~ 500Hz, 5G 12min./1cycle, period for 72min. each along X, Y, Z axes UL8750, CSA C22.2 No. 250.13-12, ENEC EN61347-1, EN61347-2-13 independent, EN62384, GB19510.1, GB19510.14,								
	SAFETY STANDARDS Note.8	EACTPTC	004,IP67 appro	).13-12, ENECT oved; Design re			ependent, EN62	2384, GB19510	.1,GB19510.14	6
SAFETY &	WITHSTAND VOLTAGE	I/P-O/P:3.7	and the second second second		and man					
EMC	ISOLATION RESISTANCE	The second second		VDC/25°C/70						
	EMC EMISSION Note.8	1	And the second second	Contract of the second second	10		000-3-3;GB177			(* 1) ×
	EMC IMMUNITY						(surge Immuni		(V);EAC TP TC	020
	MTBF	1011_4K hrs		dia SR-332 (Be	ellcore); 292	.8Khrs min.	MIL-HDBK-217	7F (25°C)		
OTHERS	DIMENSION		mm (L*W*H)							
-	PACKING	0.77Kg; 18p	cs/14.9Kg/0.82	2CUFT						
NOTE	<ol> <li>All parameters NOT special</li> <li>Please refer to "DRIVING M</li> <li>Ripple &amp; noise are measured</li> <li>Tolerance : includes set up to</li> <li>De-rating may be needed u</li> <li>Length of set up time is me</li> <li>The driver is considered as complete installation, the fin</li> <li>This series meets the typica</li> <li>Please refer to the warranty</li> <li>The armbient temperature of</li> <li>For any application note an https://www.meanwell.com</li> </ol>	IETHODS OF d at 20MHz of olerance, line nder low inpu asured at first a component al equipment al life expectan statement or derating of 3.9	ELED MODUL bandwidth by regulation and t voltages. Ple cold start. Tuu that will be op manufacturers ncy of >50,000 MEAN WELL 5°C/1000m wit roof function ir	LE". using a 12" twis load regulation rase refer to "S ming ON/OFE perated in com a must re-quali b hours of oper L's website at h th fanless mod	sted pair-wire to TATIC CHAR. the driver may bination with fi fy EMC Directi ation when To attor when To attor when To attor when To attor attor attor attor attor the stand of 5 °C.	erminated with ACTERISTIC" (lead to increat nal equipment vice on the com ase, particular anwell.com (1000m with fa	a 0.1uf & 47uf sections for de ase of the set u. Since EMC p plete installation by (c) point (or un models for o	parallel capacit etails. Ip time. erformance wi n again. TMP, per DLC perating altitud	II be affected b	°C or less.


🖫 310.616.5070 🛛 🛱 310.616.5056 🖉 eoslight.com


















🖫 310.616.5070 🛛 🖶 310.616.5056 🖉 eoslight.com